


COMMAND CENTER – ZONEXCOMMANDER (PLUS)



LEGEND

- 1** DATE AND TIME BACKUP BATTERY
- 2** SENSOR CALIBRATION:
R12 OUTSIDE AIR
- 3** POWER LED INDICATOR
- 4** MAIN CONTROL CHIP ZONEX COMMANDER (PLUS)
- 5** COMMUNICATION RS-485 TWISTED PAIR
(POLARITY SENSITIVE) (BELDEN 8740)
- 6** USB COMPUTER
- 7** SENSOR TERMINAL
OA (OUTSIDE AIR) ONLY
- 8** TERMINALS G AND B, 24VAC 40VA INPUT
- 9** ON/OFF SWITCH